


Pressure Control Assembly



Item	Part No:	Description	Qty	Item	Part No:	Description	Qty
1	0295426	Pressure Control Knob	1	15	9871056	O'Ring	1
2	9822522	Retaining Ring	1	16	0295902	Transducer Assy (torque to 180 in/lbs)	1
3	02712	Spring	1	17	9885562	O'Ring	1
4	9802895	Screw	1	18	9850640	Plug (torque to 20 ft/lbs)	1
5	9800604	Screw	3	19	0295377	Plunger	1
6	0508105	Pressure Switch	1	20	9850936	Switch	1
7	03662	Spacer	1	21	9802287	Screw (torque to 20 in/lbs)	4
8	9850577	Terminal Block	1	22	05045	Nipple	1
9	0295427	Wire hold down, 2 PLC	2	23	0275703	Strain Relief	1
10	0259415	Bracket	1	24		Cord Set	1
11	0295350	Gasket	1	25	53732	Fuse 10 amp	1
12	0295472	Control Housing	1	26	0508128	Fuse Holder	1
13	0295905	Prime / Spray Valve Assy	1	27	9802896	Screw	2
14	9885568	Barbed fitting	1	28	12440	90° elbow	1