

# Spare parts list Finish 400

Item	Order no.	Description	Item	Order no.	Description
1	9900 968	Self tapping screw	82	9900 377	Hexagon socket head cap screw
2	0253 309	Front cover			M 8 x 50 DIN 912
3	0253 310	Seal	84	0253 775	Pump head compl.
4	9900 312	Hexagon socket head cap screw	85	0253 360	Oil return hose
		M 6 x 20 DIN 912	86	0253 255	Oil dipstick compl.
5	9921 502	Spring washer A6 DIN 127	90	9900 734	Slotted cheese head screw M 4 x 45
6	0253 326	Bearing cover			DIN 84
7	9960 425	Roller	91	9922 523	Retaining ring 18 x 1.2 DIN 471
9	9904 302	Screw plug M 16 x 1.5 DIN 908	92	0158 345	Spring plate
10	9970 146	Sealing ring C 16 x 20 x 2 DIN 2603	93	0158 339	Piston D 19
11	9900 355	Hexagon socket head cap screw	94	0158 332	Piston spring
		M 8 x 45 DIN 912	95	9971 181	O-ring 51 x 2.5
12	9921 501	Spring washer A 8 DIN 127	96	0253 234	Pressure insert compl.
13	0253 776	Hydraulic component with item 77 + 79	97	0169 239	Diaphragm compl.
14	9970 528	Shaft sealing ring BA 35 x 50 x 7 DIN 3760	98	0253 364	Insert
15	9860 404	Cylindrical roller bearing	99	9971 395	O-ring 10 x 1.25
16	9920 727	Ring Nilos	100	0169 248	Relief valve compl.
17	9920 726	Spacer ring Nilos	101	0055 402	Coupler for return hose
18	9922 518	Retaining ring 35 x 1.5 DIN 471	102	0253 303	Paint section
21	0253 387	Rotor compl.	103	9921 605	Spring washer 12 DIN 7980
22	0253 388	Stator compl. 220 V ~50 Hz	104	9906 014	Hexagon socket head cap screw
	0253 396	Stator compl. 240 V ~50 Hz			M 12 x 60 DIN 912
23	9960 117	Deep groove ball bearing 6206 2Z C3	105	0010 764	Sealing ring
		DIN 625	106	0253 242	Inlet valve
24	0253 389	Disc spring	108	0253 370	Inlet valve housing
26	0253 390	Bearing end cover	109	0253 345	Inlet
27	9921 602	Spring washer B 6 DIN 7980	110	0253 218	Actuation compl.
28	0253 391	Fan	111	0253 350	Covering plate
29	0253 392	Clip	114	0253 336	Screw plug
30	0253 393	Screw M 6 x 205 (4)	115	9970 144	Sealing ring A 6.5 x 9.5 x 1 DIN 7603
31	0253 394	Fan cowl	116	0010 778	Sealing ring RD 20
40	9953 628	Motor protective switch 240/50 12 A	117	0253 236	Valve seat compl.
41	0169 353	Tongue	118	9941 501	Ball D 11
42	9951 375	Seal	119	0235 405	Spring supporting ring
48	0253 332	Terminal box	120	0010 779	Pressure spring
51	9952 820	Capacitor 40µ F 400 V	121	0253 321	Pressure screw
55	9905 103	Raised cheese head screw	122	9970 102	Sealing ring A 22 x 27 x 1.5 DIN 7603
56	0253 333	Cover	123	0253 222	End cap compl.
57	0253 386	Short instructions	125	0253 235	Outlet valve button compl.
58	0253 334	Hinged cover	126	9971 393	O-ring 10 x 2
59	0253 351	Name plate	127	9970 103	Sealing ring A 16 x 20 x 1.5 DIN 7603
63	0038 930	Earthing cable compl. 6 m (accessory)	129	9970 109	Sealing ring
68	9951 519	Mains cable compl. 6 m (220 V)	130	9991 797	Pressure gauge 0-400 bar
	9951 520	Mains cable compl. 6 m (240 V)	131	9971 365	O-ring 9.25 x 1.78
69	0253 395	Seal	132	0010 852	Control unit
71	9952 223	Terminal strip, 6 terminals	133	0010 861	Pressure spring
73	9982 804	Cable joint	134	0010 858	Clip
77	(0253 361)	Oil suction hose (included in item 13)	135	0010 859	Stop sleeve
78	0288 406	Hose clip	136	0158 251	Pressure regulation knob
79	—	Coupler (included in item 13)	137	0158 245	Pressure control valve, compl.
80	9971 172	O-ring 8 x 2.5	138	9970 505	Shaft sealing ring A 30 x 40 x 7 DIN 3760



