


**This model is obsolete  
No replacement**



Item	Part No:	Description	Qty	Item	Part No:	Description	Qty
1	0140251	Housing	1	17	0051116	Switch Ring	1
2	9932028	Roll Pin 3 x 36	2	18	9950201	Terminal Block	1
3	0048301	Stator Plates	1	19	9951216	Buckling Safety bush	1
4	0024201	Leaf Spring	1	20	0057703	Switch with ring (item17)	1
5	0140208	Drive Coil 220V-50Hz	1	21	0140307	Suction tube	1
6	0048303	Swing Armature	1	23	0140300	Container	1
7	0140409	Cover	1	24	0140576	Round jet nozzle 0.5mm	1
8	9901401	Threaded Pin 4 x 10	1	25	0032415	Swirl Valve	1
9	9905103	Recessed head screw	1	26	9951408	Mains supply	1
10	0048220	Shock absorber	1	27	0050342	Viscosity measuring cup	1
11	0024302	Piston Spring	1		0203239	Swirl Valve (3 Pack)	
12	0048250	Piston	1				
13	0016563	Brake Spring	1				
14	0046248	Stop Pad	1				
15	0140408	Regulating knob	1				
16	9951246	Switch Lead	1				